

## Sensor - Wireless Sensor

System	Code	Temperature	Humidity 3%	Display	Fan Control	Occupancy button	PIR	Set Point	Compliance	Interface	Connection	Power
Room Sensor	FX-WRZTHB00-0	Accuracy 0.6C°	x	x		x		Config	FCC /CE/	WRR Receiver	Transmission Range 15 m Recommended	3 VDC Two 1.5 VDC, AA Alkaline
	FX-WRZTHN00-0		x			x		No Dial				
	FX-WRZTHP00-0		x			x		W/C				
	FX-WRZTTB00-0			x		x		Config				
	FX-WRZTTD00-0			x	x	x		Config				
	FX-WRZTTP00-0					x		W/C				
	FX-WRZTTR00-0					x		No Dial				
	FX-WRZTTS00-0					x		Scaled				
Sensor Receiver	FX-WRZ7860-0	One to one receiver, (multi-sensor applications, upto 5 sensors)									per controller	
Bus Receiver	FX-ZFR1810-0	Bus Coordinator, Connect to FX Supervisory Controller							FCC/CE/Click	MSTP	max 8/ FX trunk	24vAC, 15 vDC
Router	FX-ZFR1811-0	Connect to Field controller, & WRZ sensor without WRZ receiver							FCC/CE/Click	SA Bus	per controller	
Accessory	FX-WRZSST-120	RF Signal test							FCC/CE/Click			
	FX-ZFRRPT-0	Power Supply for an FX-ZFR1811-0 Used as a Repeater							FCC/CE/Click			